

User menu*

Make message **6** MNO **7** PRS **8** TUV **9** WXY Exit

Messages menu*

Replay **7** PRS

Delete **3** DEF

Give **4** GHI **2** ABC Reply

Keep **5** JKL

Pause (toggle) **6** MNO

Maximise volume **0**

Skip Next **8** TUV

Skip Previous **9** WXY

Skip Last **1** QZ

Skip First **2** ABC **2** ABC Call back

Rewind *****

Fast Forward **#**

User options* menu

6 MNO record Name & Greeting

7 PRS change Password

8 TUV additional User options

Additional user options* menu

Access another mailbox **2** ABC

Mailbox diversion options **3** DEF

Nominate active greeting **4** GHI

Setup distribution Lists **5** JKL

Notification options **6** MNO

Record additional greetings **7** PRS

**options may be restricted*

Part Number: 100-09001-EN

Made in Australia

E: support@voicenet.net.au
 F: +61 2 997 7244
 T: +61 2 997 7233
 www.voicenet.com.au

Voicenet User Guide

Instructions for use:

Dial or

pilot external number

Voicemail Main Menu:
enter # then mailbox number

Mailbox:
...says "Hello..."

Mailbox:
enter your password (if any)

Mailbox:
plays any new messages (if any)

Mailbox User Menu:
6 **(7)** **8** **9**

Make a message for another mailbox

Play unplayed messages (if any)

User Options Menu

Exit